


CBS CODES:

CHANGING YOUR KEYBOX'S CBS CODE

Each keybox comes with a randomly generated CBS code. You can change your codes within the Supra E-Key App. The keybox must be in "My Keyboxes" and you must have the shackle code and be near the box to make this change.



Once you have made the change, select program at the bottom of the screen. You will be prompted to enter the keybox shackle code. Be sure to push up on the bottom of the lockbox to activate the bluetooth and make the red light flash on the front of the box.

First, select the keybox serial number under My Keyboxes, To change the CBS code, tap on the number with your finger. This will place the cursor behind the number. You can edit this number to be any 7 digits you'd like. (We ask that you do not use codes like 1234567, as this makes the keybox access less secure. Do not put CBS codes in listing notes in MLS)

